

Instructions for Fastening Machine to Cart

Hardware included with Cart.

1. Unplug machine from power.
2. Remove machine clean-out tray to provide access to the four square holes in the bottom of the machine.
3. Set the machine on the cart tray and align the four square holes in the machine with the four round holes in the cart shelf.
4. Slip the four carriage bolts through the aligned holes from the top (machine side).
5. Screw the four wing nuts on the four carriage bolts extending through the bottom of the cart shelf. Hand-tighten the wing nuts securely. There will be gap between machine bottom and cart shelf by design.
6. Replace machine clean-out tray.

